REVISED STARTING SERIAL # 150410237

PARTS LIST MANUAL

HEAVY-DUTY FLOOR GRINDER / POLISHER

PROPANE MODELS







MODEL 2DP-18P SKU # 53900P

EQUIPMENT DEVELOPMENT COMPANY, INC.



READ AND UNDERSTAND THE OPERATORS INSTRUCTION MANUAL THOROUGHLY BEFORE ATTEMPTING TO OPERATE THIS EQUIPMENT.

Death or serious injury could occur if this machine is used improperly.



SAFETY MESSAGES

· Safety Instructions are proceeded by a graphic alert symbol of DANGER, WARNING, or CAUTION.



Indicates an imminent hazard which, if not avoided, will result in death or serious injury.



Indicates an imminent hazard which, if not avoided, can result in death or serious injury.



Indicates hazards which, if not avoided, could result in serious injury and or damage to the equipment.

GASOLINE/PROPANE POWERED EQUIPMENT



 Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.



- Gasoline is extremely flammable and poisonous. It should only be dispensed in well ventilated areas, and with a cool engine.
- · Small gasoline engines produce high concentrations of carbon monoxide (CO) example: a 5 HP 4 cycle engine operation in an enclosed 100,000 cu. ft. area with only one change of air per hour is capable of providing deadly concentrations of CO in less than fifteen minutes. Five changes of air in the same area will produce noxious fumes in less than 30 minutes. Gasoline or propane powered equipment should not be used in enclosed or partially enclosed areas. Symptoms of CO poisoning include, headache, nausea, weakness, dizziness, visual problems and loss of consciousness. If symptoms occur - get into fresh air and seek medical attention immediately.

ELECTRICAL POWERED EQUIPMENT



Extreme care must be taken when operating electric models with water present: Ensure power cord is properly grounded, is attached to a Ground-Fault-Interrupter (GFI) outlet, and is undamaged.

- Check all electrical cables be sure connections are tight and cable is continuous and in good condition. Be sure cable is correctly rated for both the operating current and voltage of this equipment.
- Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with qualified electrician or service person if there is any doubt as to whether the outlet is properly grounded. Adhere to all local codes and ordinances.
- **NOTE:** In the event of a malfunction or breakdown, grounding provides a path of least resistance for the electric current to dissipate. The motor is equipped with a grounded plug and must be connected to an outlet that is properly installed and properly grounded. DO NOT modify the plug provided on the motor. If the plug does not fit the outlet have a qualified electrician install the proper receptacle.
- Switch motor OFF before disconnecting power.

- · Do not disconnect power by pulling cord. To disconnect, grasp the plug, not the cord.
- Unplug power cord at the machine when not in use and before servicing.

GENERAL INSTRUCTIONS

- Equipment should only be operated by trained personnel in good physical condition and mental health (not fatigued). The operator and maintenance personnel must be physically able to handle the bulk weight and power of this equipment.
- This is a one person tool. Maintain a safe operating distance to other personnel. It is the operators' responsibility to keep other people (workers, pedestrians, bystanders, etc.) away during operation. Block off the work area in all directions with roping, safety netting, etc. for a safe distance. Failure to do so may result in others being injured by flying debris or exposing them to harmful dust and noise.
- · This equipment is intended for commercial use only.
- For the operator's safety and the safety of others, always keep all guards in place during operation.
- Never let equipment run unattended.

















· Personal Protection Equipment and proper safety attire must be worn when operating this machinery. The operator must wear approved safety equipment appropriate for the job such as hard hat and safety shoes when conditions require. Hearing protection MUST be used (operational noise levels of this equipment may exceed 85db). Eye protection MUST be worn at all times.



Keep body parts and loose clothing away from moving parts. Failure to do so could result in dismemberment or death.

- Do not modify the machine.
 - Stop motor/engine when adjusting or servicing this equipment. Maintain a safe operating distance from flammable materials. Sparks from the cutting-action of this machine can ignite flammable materials or vapors.

DUST WARNING



Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to cause cancer. birth defects, or other reproductive harm. Some examples of these chemicals are:

- · Lead from lead-based paints, and
- Crystalline silica from bricks and concrete and other masonry products.

Your risk of exposure to these chemicals varies depending on how often you do this type of work. To reduce your risk: work in a well ventilated area, use a dust control system, such as an industrial-style vacuum, and wear approved personal safety equipment, such as a dust/particle respirator designed to filter out microscopic particles.

EQUIPMENT DEVELOPMENT COMPANY. INC.

PARTS LIST MANUAL HEAVY-DUTY FLOOR GRINDER/POLISHER

PROPANE MODELS

TABLE OF CONTENTS

<u>Section</u>	<u>Page Number</u>
Safety Messages and General Instructions	2
How To Order Replacement Parts	3
Illustration 1: Main Grouping	4, 5
Illustration 2: Handle & Wheel Carriage Grouping	6, 7
Illustration 3: Skirt, Vacuum Port & Water Hook-Up Grouping	8, 9
Illustration 4: Disc Assembly	10
Illustration 5: Disc Arrangement	11
Illustration 6: Propane Engine & Belt Drive Grouping	12, 13
Illustration 7: Propane Tank Grouping	14, 15
Illustration 8: Electrical Component Grouping	16, 17
Wiring Diagram	
Blank Page	19
Decal Sheet 1	20
Decal Sheet 2	21
Blank Page	22
Notes	23
Limited Equipment Warranty of Sale - Terms & Conditions	24 (Back Page)

HOW TO ORDER REPLACEMENT PARTS

- ☐ To insure product safety and reliability, always use genuine EDCO replacement parts when making repairs to the equipment.
- □ When calling for parts, specify the MODEL and SERIAL number of the machine, which can be found on the NAME PLATE. Keep that information in the space provided. In addition to this information, give part number, description, and quantity as listed on the parts list to your parts representative.
- Please note: Due to improvements and changes in the equipment, the illustrations shown may be different than the actual machine.


FILL IN INFORMATION BELOW

Date of Purchase ______

Model # _____

Serial # _____


SKU # _____



	PARTS LIS	TING - ILLUSTRATION 1 : MAIN GROUPING	
ITEM#	PART#	DESCRIPTION	QTY.
1	77501	MAIN FRAME	1
2	77502P	COVER, GEAR CASE (PROPANE)	1
3	10005	PLUG, HOLE 7/8" BRIGHT ZINC	1
4	11697	SCREW, FLANGE HEX 1/4-20 X 3	2
5	10018	SCREW, CAP 1/4-20 X 3/4	6
6	10038	WASHER, LOCK 1/4 ZINC	8
7	10602	WASHER, FLAT 1/4 SAE ZINC	6
8	77008	BEARING, BALL 1" 4-HOLE FLANGE, ND	4
9	10450	WASHER, LOCK 7/16 ZINC	16
10	10481	NUT, HEX 7/16-20 ZINC	16
11	77009	BEARING, BALL 3/4" 4-HOLE FLANGE	2
12	50541	ADAPTER, GREASE FIT. 1/8PT X 1/4-28	1
13	10699	PIPE NIPPLE 1/8NPT X 2" (BLACK)	1
14	10585	PIPE COUPLING 1/8 NPT (BLACK STEEL)	1
15	10953	FITTING, GREASE 1/8 NPT STRAIGHT	1
16	10960	FITTING, GREASE 1/4-28 X 45°	3
17	10309	SCREW, CAP 3/8-24 X 1-1/4 ZINC	4
18	10811	WASHER, LOCK 3/8 ZINC	4
19	10014	NUT, HEX 3/8-24 ZINC	4
20	77346	SHAFT, LARGE GEAR 1"DIA X 7"L	2
21	77012	GEAR, SPUR 112 TOOTH (DRIVEN)	2
22	63056	PIN, H.D.COILED SPRING 3/8 X 2-1/2	2
23	77011	SHAFT, PINION GEAR 3/4DIA X 7-3/8"L	1
24	10037	PIN, ROLL 1/4 X 1-1/2	1
25	77053	GEAR, SPUR 25 TOOTH (PINION)	1
26	10009	WASHER, FLAT 3/4 SAE ZINC	1
27	77535	DISC ASSY. COMPLETE (REFER TO ILLUSTRATION 4 FOR BREAKDOWN)	2
28	10063	PIN, ROLL 3/8 X 2	2
29	77531	HOOD, PROPANE MODEL	1
30	10025	WASHER, FLAT 3/8 SAE ZINC	2
31	10811	WASHER, LOCK 3/8 ZINC	2
32	10907	SCREW, CAP 3/8-16 X 3/4	2
33	77506	WEIGHT BLOCK, 40 LB.	2
34	77532	LIFTING BAIL	1
35	10025	WASHER, FLAT 3/8 SAE ZINC	4
36	10811	WASHER, LOCK 3/8 ZINC	4
37	10309	SCREW, CAP 3/8-24 X 1-1/4 ZINC	4
38	77554	BRACKET, MUFFLER, 2DP/2DHDP-18P	2
39	10320	BOLT, CARRIAGE 3/8-16 X 1-1/4 F.T.	2
40	10025	WASHER, FLAT 3/8 SAE ZINC	2
41	10156	NUT, HEX NYLON LOCK 3/8-16 ZINC	2

EQUIPMENT DEVELOPMENT COMPANY, INC. 100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA
Phone: 800-638-3326 or 301-663-1600 • Fax: 800-447-3326 or 301-663-1607
Website: www.edcoinc.com • E-mail: sales@edcoinc.com




EQUIPMENT DEVELOPMENT COMPANY, INC.100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA

PART	S LISTING - II	LLUSTRATION 2 : HANDLE & WHEEL CARRIAGE GROU	PING
ITEM#	PART#	DESCRIPTION	QTY.
1	77533	HANDLE BAR, PROPANE MODEL	1
2	10608	GRIP, HAND 1" MODEL AT	2
3	10029	SCREW, CAP 3/8-24 X 1-3/4	4
4	10025	WASHER, FLAT 3/8 SAE ZINC	8
5	10004	NUT, HEX LOCK 3/8-24 ZINC	4
6	77508	HANDLE EXTENSION	1
7	77528	PLUG, BLACK 1"RD. TUBING 10-14 GA.	2
8	10030	SCREW, CAP 3/8-24 X 2	2
9	10025	WASHER, FLAT 3/8 SAE ZINC	4
10	10004	NUT, HEX LOCK 3/8-24 ZINC	2
11	65019	HANDWHEEL, SMALL W/ 5/8-8 X 13"ROD	1
12	14023	KNOB, BALL 1-3/8 W/ 1/2-13THD, BLK.	1
13	50550	SLEEVE, BRASS 1/2" TAPERED	1
14	10346	SCREW, SKT. HD. CAP 1/2-13 X 4-1/2	1
15	80009	BEARING, BALL 5/8" 2-HOLE (NO G.F.)	1
16	55010	SPACER, HANDWHEEL 5/8"ID X 3/4"L	1
17	10096	COLLAR, LOCKING 5/8"ID	2
18	10412	BOLT, CARRIAGE 1/4-20 X 1	2
19	10602	WASHER, FLAT 1/4 SAE ZINC	2
20	10861	NUT, KEPS LOCK 1/4-20 ZINC	2
21	10808	FITTING, GREASE 1/4-28 STRAIGHT	1
22	77534	LINKAGE, LOWER	1
23	10343	SCREW, CAP 1/2-20 X 2-1/2	1
24	10154	NUT, HEX NYLON LOCK 1/2-20 ZINC	1
25	77510	CARRIAGE, WHEEL	1
26	77537	FORK SHAFT 3/4"DIA. X 13-3/4"L	1
27	68008	WHEEL 8 X 1-5/8 X 3/4"BRG., POLY	2
28	77520	WHEEL 4 X 1-1/2 X 3/4"BRG., POLY	2
29	10009	WASHER, FLAT 3/4 SAE ZINC	14
30	10428	COLLAR, LOCKING 3/4"ID	6
31	77501	MAIN FRAME (REFER TO ILLUS. 1)	1

EQUIPMENT DEVELOPMENT COMPANY, INC. 100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA


ILLUSTRATION 3: SKIRT, VACUUM PORT & WATER HOOK-UP GROUPING



EQUIPMENT DEVELOPMENT COMPANY, INC.100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA


	SKIRT,	PARTS LISTING - ILLUSTRATION 3 : VACUUM PORT & WATER HOOK-UP GROUPING	
ITEM#	PART#	DESCRIPTION	QTY.
1	77529	RUBBER SKIRT 1/8 X 8 X 58 W/VELCRO	1
2	77504	RUBBER SKIRT, REAR 1/8 X 4 X 11	1
3	10018	SCREW, CAP 1/4-20 X 3/4	2
4	10038	WASHER, LOCK 1/4 ZINC	2
5	10602	WASHER, FLAT 1/4 SAE ZINC	2
6	86357	VELCRO-HOOK, 2" WIDE, WATER RESISTANT 1 PIECE CUT 57-1/4"L & 2 PIECES CUT 5-1/4"L	6 FT. TOTAL
7	77551	HOSE, FLEX 2"ID X 36"L	1
8	10766	CLAMP, HOSE, SAE #32, ADJ. TO 2-1/2	2
9	77538	VACUUM PORT	1
10	65021	CAP/PLUG 2" RED PLASTIC, FLANGED	1
11	10846	SCREW, CAP STSHW 1/4-20 X 1/2	2
12	10038	WASHER, LOCK 1/4 ZINC	2
13		SIDE PANELS, HANDLE (REFER TO ILLUS. 7)	2
14	77533	HANDLE BAR, PROP. MODEL (REFER TO ILLUS. 2)	1
15	80021	CONN., SWIVEL FEM. 3/4HOSE X 1/2MPT	1
16	10711	VALVE, BALL 1/2 FPT	1
17	50075	BARB, 3/8 HOSE X 1/4MPT (BRASS)	1
18	77521	HOSE 3/8"ID X 18"L	1
19	50069	CLAMP, HOSE, SAE #6, ADJ. TO 13/16	2
20	10694	BARB, 3/8HOSE X 1/8MPT	1
21	10772	ELBOW, STREET 1/8NPT X 45 (BRASS)	1
22	77501	MAIN FRAME (REFER TO ILLUS. 1)	1

ILLUSTRATION 4: DISC ASSEMBLY



DISC ASSEMBLY COMPLETE PART # 77535 (ITEMS 1 THRU 12)

DISC LOWER HALF SUB-ASSEMBLY PART # 77536 (ITEMS 1 THRU 6)



ITEM#	PART#	DESCRIPTION	QTY.*	
1	75175	DISC, QUICK-CHANGE	1	
2	QC-HOLDER-EDCO	HOLDER, MAGNETIC QUICK CHANGE	3	
3	10147	SCREW, FLAT HD SKT 1/4-20 X 3/4	6	
4	L18567	DISC TOP PLATE	1	
5	11614	SCREW, CAP 1/2-20 X 3/4	3	
6	10045	WASHER, LOCK 1/2 ZINC	3	
7	86017	COUPLING, MORFLEX 402 CENTER	1	
8	77518	FLANGE, MORFLEX COUPLING	1	
9	10114	SCREW, SKT. HD. CAP 3/8-24 X 2-1/4	4	
10	11695	WASHER, 1.1210 X .3750 X .1280	2	
11	86343	BUSHING, RUBBER 1-1/4 X 3/4 X 3/8	4	
12	10004	NUT, HEX LOCK 3/8-24 ZINC	4	
*N	*NOTE: QUANTITIES ARE BASED ON 1 DISC. 2 DISC ARE REQUIRED.			

ILLUSTRATION 5: DISC ARRANGEMENT





ILLUSTRATION 6: PROPANE ENGINE & BELT DRIVE GROUPING




EQUIPMENT DEVELOPMENT COMPANY, INC.100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA

PAR	TS LISTING -	ILLUSTRATION 6 : PROPANE ENGINE & BELT DRIVE GROU	PING
ITEM#	PART#	DESCRIPTION	QTY.
1	15081	ENGINE, KAWASAKI FS600V PROP. READY INCLUDES: 12V STARTER, OIL PRESSURE SWITCH, OIL DRAIIN, CATALYTIC MUFFLER. LP FUEL SYSTEM: REGULATOR, INLINE SHUT-OFF VALVE, HIGH & LOW PRESSURE HOSES, & REGO TANK CONNECTOR.	1
2	77539	MOUNT, ENGINE, PROPANE	1
3	10055	SCREW, CAP 3/8-16 X 1	8
4	10811	WASHER, LOCK 3/8 ZINC	8
5	10025	WASHER, FLAT 3/8 SAE ZINC	8
6	77540	SPACER, CLUTCH, PROPANE MODEL	1
7	10139	SCREW, SET 1/4-20 X 5/16	1
8	40317	KEY 1/4SQ X 1-5/8	1
9	77541	BRACKET, CLUTCH RETAINER	1
10	10004	NUT, HEX LOCK 3/8-24 ZINC	2
11	75182	CLUTCH, ELECTRIC, 1 GR00VE	1
12	77542	WASHER, CLUTCH RETAINING 1-1/4"OD X 1/2"ID X 3/16"THK	1
13	10450	WASHER, LOCK 7/16 ZINC	1
14	11699	SCREW, CAP 7/16-20 X 1-3/4	1
15	10277	BELT B-38	1
16	10549	SHEAVE 7"OD X 1GR.B X 3/4"BORE	1
17	10016	KEY 3/16SQ X 1-1/2	1
18	75173	BATTERY 12V, DEKA ETX20L	1
19	77543	RUBBER PAD, BATTERY 3/16 X 3-3/8 X 7	1
20	77544	RUBBER PAD, BATTERY 3/16 X 1-1/2 X 9	1
21	77545	CLAMP, BATTERY HOLD-DOWN	1
22	10018	SCREW, CAP 1/4-20 X 3/4	2
23	10038	WASHER, LOCK 1/4 ZINC	2
24	10602	WASHER, FLAT 1/4 SAE ZINC	2
25	77546	BRACKET, BATTERY	1
26	10055	SCREW, CAP 3/8-16 X 1	1
27	10811	WASHER, LOCK 3/8 ZINC	1
28	10025	WASHER, FLAT 3/8 SAE ZINC	1
29	3611	CABLE, THROTTLE, LEVER-TYPE 54" (TRIMMED TO 44"LOA)	1
30	10877	SCREW, CAP STSHW 10-24 X 1/2	3
31	10831	WASHER, LOCK, INT. TOOTH #10	3
32	10941	CLIP, CONDUIT, THROTTLE CABLE	1

EQUIPMENT DEVELOPMENT COMPANY, INC.


100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA
Phone: 800-638-3326 or 301-663-1600 • Fax: 800-447-3326 or 301-663-1607
Website: www.edcoinc.com • E-mail: sales@edcoinc.com

ILLUSTRATION 7: PROPANE TANK GROUPING



EQUIPMENT DEVELOPMENT COMPANY, INC.100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA

PARTS LISTING ILLUSTRATION 7: PROPANE TANK GROUPING			
ITEM#	PART#	DESCRIPTION	QTY.
1	15130	PROPANE TANK 20LB. HORZ./VERT.	1
2	N/A	DECAL, ARROW, RED (SEE DECAL SHEET 1)	1
3	77061-1	PROPANE TANK CRADLE BRACKET ONLY	1
4	77061-2	PROPANE TANK STRAP W/ HINGE	1
5	77061-3	PROPANE TANK CLAW BRACKET	1
6	77061-4	PROPANE TANK TOGGLE CLAMP	1
7	11661	SCREW, FLAT HD SLT 1/4-20 X 1	4
8	10602	WASHER, FLAT 1/4 SAE ZINC	4
9	10861	NUT, KEPS LOCK 1/4-20 ZINC	4
10	10802	BOLT, CARRIAGE 3/8-16 X 1 ZINC	4
11	10025	WASHER, FLAT 3/8 SAE ZINC	4
12	10811	WASHER, LOCK 3/8 ZINC	4
13	10404	NUT, HEX 3/8-16 ZINC	4
14	77547	DECK, PROPANE TANK	1
15	77548	SIDE PANEL, HANDLE RIGHT	1
16	77549	SIDE PANEL, HANDLE LEFT	1
17	10021	SCREW, CAP 3/8-24 X 1	4
18	10025	WASHER, FLAT 3/8 SAE ZINC	8
19	10004	NUT, HEX LOCK 3/8-24 ZINC	4
20	10029	SCREW, CAP 3/8-24 X 1-3/4	4
21	10025	WASHER, FLAT 3/8 SAE ZINC	8
22	10004	NUT, HEX LOCK 3/8-24 ZINC	4



EQUIPMENT DEVELOPMENT COMPANY, INC.100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA


PARTS LISTING ILLUSTRATION 8: ELECTRICAL COMPONENT GROUPING			
ITEM#	PART#	DESCRIPTION	QTY.
1	15201A	SWITCH W/ WIRES, ROCKER RED ON-OFF	1
		(EMERGNCY STOP)	
	50084	ADDITIONAL PARTS REQ'D. (NOT SHOWN): TERM., RING #10 16-14GA. INSULATED	1
	10831	WASHER, LOCK, INT. TOOTH #10	1
	10877	SCREW, CAP STSHW 10-24 X 1/2	1
	11567	CONNECTOR, BULLET STD. 16-14GA.BLUE	1
2	75184	SWITCH, ROCKER ON-OFF, RED, CLUTCH	1
3	15264	LAMP, OIL PRESSURE, RED	1
4	10633	SWITCH, TOGGLE SPST 15/10A-115/250V	1
5	10674	BOOT, TOGGLE SWITCH	1
6	75183	SWITCH, KEY STARTER	1
7	75171	SOLENOID SWITCH, STARTER	1
8	10018	SCREW, CAP 1/4-20 X 3/4	2
9	10602	WASHER, FLAT 1/4 SAE ZINC	2
10	10861	NUT, KEPS LOCK 1/4-20 ZINC	2
11		SAFETY VALVE, INLINE SHUT-OFF, AFC #152	1
		THIS IS INCLUDED WITH THE ENGINES	
40	40550	LP FUEL SYSTEM (REFER TO ILLUS. 7)	4 5 5
12	16550	LOOM, FLEX 1/4" X 45"	4 FT.
13	10982	TIE, CABLE, BLACK NYLON 11-1/4"	1
14	41124	CLAMP, CONDUIT 1/2"EMT (SNAP-STRAP)	1
15	10004	NUT, HEX LOCK 3/8-24 ZINC	1
16	75170	HEADLIGHT (REFER TO ILLUS. 1)	1
17	10877	SCREW, CAP STSHW 10-24 X 1/2	3
18	10831	WASHER, LOCK, INT. TOOTH #10	4
19	57148	GROMMET 3/8ID X 1/8GRV. X 5/8GD	1
20	75173	BATTERY 12V, DEKA ETX20L (REFER TO ILLUS. 6)	1
21	75182	CLUTCH, ELECTRIC, 1 GR00VE (REFER TO ILLUS. 6)	1
NOT	75180	FUSEHOLDER, 1-30A, ATC BLADE	1
SHOWN	75181	FUSE, 20A, ATC BLADE	1

EQUIPMENT DEVELOPMENT COMPANY, INC. 100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA

WIRING DIAGRAM

SELECT HERE FOR REVISED WIRING DIAGRAM STARTING S/N 151210056


REVISED STARTING SERIAL #150410237



EQUIPMENT DEVELOPMENT COMPANY, INC.

THIS PAGE LEFT BLANK INTENTIONALLY

DECAL SHEET 1



EQUIPMENT DEVELOPMENT COMPANY, INC.

DECAL SHEET 2

2DP, 2D-HDE, 2D-HDG 14 x 17 4-EC & 4-GC P/N 92223-2 RevC







Propane Models:



To Start the Engine:

- o Start the Engine:

 Ensure that tank is positioned properly (arrow up),

 Turn on main valve on tank & Emergency Stop switch on handle,

 If you delect a gas odor immediately shut off engine and consult your operator's manual,

 Turn key to start.

 Open throttle completely until engine runs smooth.

 Adjust throttle back to idle and sit machine back on surface.

- Increase speed to operating position & begin grinding.

To Stop the Propane Model:

NOTE: If engine stops abruptly (uncontrolled stop) or using E-STOP wait several minutes for propane gas to clear the fuel system and carbinutor before trying to re-start.

- If the machine back slightly to allow the disc to clear the slab surface.

- If stopping for the day close valve and allow machine to purge propane from system.

- Turn Key and emergency switch off.

- Otherwise just turn key off.

Propane Models:



VAPOR ONLY

To Start the Engine:

- Start the Engine:
 Ensure that tank is positioned properly (arrow up).
 Turn on main valve on tank & Emergency Stop switch on handle,
 If you detect a gas ador immediately shut off engine and consult your operator's manual,
 Turn key to start.
 Open throttle completely until engine runs smooth.
 Adjust throttle back to telle and sit machine back on surface.

- Increase speed to operating position & begin grinding.

To Stop the Propane Model:

NOTE: If engine stops abruptly (uncontrolled stop) or using E-STOP wait several minutes for propane gas to clear the fuel system and carburator before trying to re-start.

- Tilt the machine back slightly to allow the disc to clear the slab surface.

- If stopping for the day close valve and allow machine to purge propane from system.

- Turn Key and emergency switch off.

- Otherwise just turn key off.

EQUIPMENT DEVELOPMENT COMPANY, INC.

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone: 800-638-3326 or 301-663-1600 • Fax: 800-447-3326 or 301-663-1607

Website: www.edcoinc.com • E-mail: sales@edcoinc.com

E-2DHDP18P-PL-0415

THIS PAGE LEFT BLANK INTENTIONALLY

NOTES

Record here any repairs or changes made to the Equipment				

LIMITED EQUIPMENT WARRANTY OF SALE - TERMS & CONDITIONS

Equipment Development Company, Inc. herein referred to as EDCO (Seller) warrants that each new unit manufactured by EDCO to be free from defects in material and workmanship in normal use and service for a period of (1) one year (except for the cutter drum assembly on all model concrete/asphalt planes, in which case the warranty period shall be 90 days) from date of shipment to the original retail or equipment rental center owner.

Accessories or equipment furnished and installed on the product by EDCO but manufactured by others, including, but not limited to engines, motors, electrical components, transmissions etc., shall carry the accessory manufacturers own warranty.

EDCO will, at its option, repair or replace, at the EDCO factory or at a point designated by EDCO, any part which shall appear to the satisfaction of EDCO inspection to have been defective in material or workmanship.

EDCO reserves the right to modify, alter and improve any part or parts without incurring any obligation to replace any part or parts previously sold without such modified, altered or improved part or parts.

This warranty is in lieu of and excludes all other warranties, expressed, implied, statutory, or otherwise created under applicable law including, but not limited to the warranty of merchantability and the warranty of fitness for a particular purpose in no event shall seller or the manufacturer of the product be liable for special, incidental, or consequential damages, including loss of profits, whether or not caused by or resulting from the negligence of seller and/or the manufacturer of the product unless specifically provided herein. In addition, this warranty shall not apply to any products or portions there of which have been subjected to abuse, misuse, improper installation, maintenance, or operation, electrical failure or abnormal conditions and to products which have been tampered with, altered, modified, repaired, reworked by anyone not approved by seller or used in any manner inconsistent with the provisions of the above or any instructions or specifications provided with or for the product

FORCE MAJEURE

Seller's obligation hereunder are subject to, and Seller shall not be held responsible for, any delay or failure to make delivery of all or any part of the Product due to labor difficulties, fires, casualties, accidents, acts of the elements, acts of God, transportation difficulties, delays by a common carrier, inability to obtain Product, materials or components or qualified labor sufficient to timely perform part of or all of the obligations contained in these terms and conditions, governmental regulations or actions, strikes, damage to or destruction in whole or part of manufacturing plant, riots, terrorist attacks or incidents, civil commotions, warlike conditions, flood, tidal waves, typhoon, hurricane, earthquake, lightning, explosion or any other causes, contingencies or circumstances within or without the United States not subject to the Seller's control which prevent or hinder the manufacture or delivery of the Products or make the fulfillment of these terms and conditions impracticable. In the event of the occurrence of any of the foregoing, at the option of Seller, Seller shall be excused from the performance under these Terms and Conditions, or the performance of the Seller shall be correspondingly extended.

This document sets forth the terms and conditions pursuant to which the purchaser ("Purchaser") will purchase and Equipment Development Co.lnc. ("Seller") will sell the products, accessories, attachments (collectively the Products ") ordered by the Purchaser. These terms and conditions shall govern and apply to the sale of Seller's Products to Purchaser, regardless of any terms and conditions appearing on any purchase order or other forms submitted by Purchaser to Seller, or the inconsistency of any terms therein and herein.

1. PRICE

All prices set forth on any purchase order or other document are F.O.B. Sellers facility or distribution point, as may be determined by Seller (F.O.B.Point). All prices are exclusive of any and all taxes, including, but not limited to, excise, sales, use, property or transportation taxes related to the sale or use of the Products, now or hereafter imposed, together with all penalties and expenses. Purchaser shall be responsible for collecting and/or paying any and all such taxes, whether or not they are stated in any invoice for the Products. Unless otherwise specified herein, all prices are exclusive of inland transportation, freight, insurance and other costs and expenses relating to the shipment of the Products from the F.O.B. point to Purchaser's facility. Any prepayment by Seller of freight insurance and other costs shall be for the account of Purchaser and shall be repaid to Seller.

2. PAYMENT TERMS

Payment terms are as follows. 2% 10 days (to approved and qualified accounts). Net 30 days. This is a cash discount for invoices paid within 10 days after the invoice date, regardless of date of receipt of shipment. This is not a trade discount and will not be granted to accounts that do not adhere to stated terms.

- *All past due accounts are subject to a late payment fee of 1.5% per month or a maximum allowed by law if different, along with the expenses incidental to collection including reasonable attorney's fees and costs.
- *Seller reserves the right to hold shipments against past due accounts.
- *Seller reserves the right to alter payment terms.

3. FREIGHT TERMS

All shipments will be made F.O.B. shipping point as designated in these Terms and Conditions, and title shall pass at the F.O.B. point. Delivery to the initial common carrier shall constitute delivery to the Purchaser. Any claims for loss or damage during shipment are to be filed with carrier by the Purchaser. Seller will not assume responsibility for the performance of the carrier.

Back orders will be shipped in the most practical fashion with charges consistent with our freight policy established with the original order. UPS, FED EX, MAIL or shipments by other couriers are subject to the same terms and conditions as outlined in paragraph #3"Freight Terms".

4. DELIVERY, DAMAGES, SHORTAGES

Seller shall use reasonable efforts to attempt to cause the Products to be delivered as provided for in these Terms & Conditions. Delivery to the initial common carrier shall constitute the delivery to the Purchaser. Sellers responsibility, in so far as transportation risks are concerned ceases upon the delivery of the Products in good condition to such carrier at the F.O.B. point and all the Products shall be shipped at the Purchaser's risk. Seller shall not be responsible or liable for any loss of income and/or profits, or incidental, special, consequential damages resulting from Seller's delayed performance in shipment and delivery.

5. RETURN OF DEFECTIVE PRODUCTS

Defective or failed material shall be held at the Purchaser's premises until authorization has been granted by Seller to return or dispose of Products. Products that are to be returned for final inspection must be returned Freight Prepaid in the most economical way. Credit will be issued for material found to be defective upon Seller's inspection based on prices at time of purchase.

6. PRODUCTS ORDERED IN ERROR

Products may be returned, provided that claim is made and Seller is notified within 7 days of receipt of Products, and the Products are in original buyer's possession not more than 30 days prior to return, subject to Seller's approval. If Products are accepted for return, they must be Freight Prepaid and buyer will be charged a minimum of 15% restocking charge, plus a charge back for outbound freight charges if the original order was shipped prepaid. Returns are not accepted for any Products that are specifically manufactured to meet the buyer's requirement of either specifications or quantity.

AGREEMENTS

These Terms and Conditions constitute the entire agreement between Seller and Purchaser as it relates to terms and conditions of sale, and supersedes any and all prior oral or written agreements, correspondence, quotations or understandings heretofore in force between the parties relating to the subject matter hereof. There are no agreements between Seller and Purchaser with respect to the Product herein except those specifically set forth in and made part of these terms and conditions. Any additional terms, conditions and/or prices are rejected by Seller.

These terms and conditions may be modified, cancelled or rescinded only by a written agreement of both parties executed by their duly authorized agents.

USE ONLY GENUINE EDCO PARTS & ACCESSORIES
For your own safety, the safety of others and the life of your machine.

Equipment Development Company, Inc.

EQUIPMENT DEVELOPMENT COMPANY, INC.

WIRING DIAGRAM FOR MODEL 2DHDP/2DP-18P

REVISED STARTING SERIAL #151210056

